

Trouble shooting

Fault	Possible causes	Action
Alarm + display message: "CHECK UNIT" "->CUSTOMER SERVICE"	Various defects Water tank empty Sensor breakage/short circuit T1	Customer Service* Fill up water* Customer Service*
Alarm + display message: "CHECK UNIT" "->CTEMPERATURE TOO LOW"	1. Unit too cold (< 9°C)	Warm up the unit for some time at room temperature*
	2. Sensor breakage T2	2. Customer Service*
	3. Water tank frozen	 Allow the unit to thaw*; Check the unit for frost damage (does water run out of the unit?) → customer service
Unit completely without function and audible alarm	Mains failure	Switch off the unit, until the mains supply is up again
	2. Mains plug has no contact	Check plug on unit and mains socket for correct fit
	3. Fuse defective	Customer Service*
	4. Unit defective	4. Customer Service*

^{*} Switch off the unit immediately