Step3: service

with lym

Lyse tubing not replaced LEO:

Diluent or leftover waste gets to sample earlier than LEOI.

resulting in hemolytic

Figure 7-5 Analyzing process of low WBC results

VI2 leakage, drives

a large amount of sample into flow

Verify per above procedure if SP and sample preparation is normal no need to perform cleaning and maintenance

verified per this

method- instead of just cleaning flow cell.