



4.6.8 Adjusting the brakes


- Adjust the brakes so that the device elements stop and remain in position after any change in position.



Brake for the swivel arm socket



Brake at the swivel joint of the swivel arm/dentist unit



Brake at the swivel joint of the swivel arm/dentist unit