

The diagram illustrates the internal components and connections of the E-box/Power supply system. Key components and their connections are as follows:

- E-box/Power supply:** The main power unit, shown in a side view and a rear view. It features a control module top and a rear I/O panel.
- Video monitor:** Connected to the system via a cable that is part of the video monitor assembly (453561227761).
- Left speaker and Right speaker:** Connected to the system via a cable (453561222271).
- PCC board:** The Personal Computer Card board, connected to the system via a cable (453561227931).
- Control module Splitter board:** Connected to the system via a cable (453561226091).
- Hard drive and Disk drive:** Connected to the system via a cable (453561232921).
- B/W printer (Figure 11-1) and Color printer (Figure 11-2) VCR (Figure 11-3):** Connected to the system via a cable (2275-0482-01).
- Transformer:** Connected to the system via a cable (453561226851).
- Inside connectors:** JP1, JP2, JP3, JP4, JP5.
- Power connector panel:** Connected to the system via a cable (453561225681).
- Outside connectors:** Connected to the system via a cable (453561225711).

For more information, see the [Cable Parts List](#) for power cord part numbers.