

MAX88K-Parts Enumeration

PART LIST			
NO.	NAME	Q'TY	P/N
1	NOSE CAP COVER	1	BL800K-11005
2	DUST SEAL	1	BL800K-11006
3	SEAL COVER	1	BL800K-11009
4	DUST COLLECTOR	1	BL800K-11007
5	NOSE CAP	1	BL800K-11001
6	O-RING	1	BL800K-11003
7	TEST BAR	1	NX100S-10211
8	COLLET CHUCK	1	BL800K-11311
9	COLLET CHUCK CASE	1	BL800A-11301
10	BALL BEARING	1	BL800A-11304
11	BEARING STOPPER	2	BL800A-11305
12	BEARING COVER	1	BL800A-11306
13	CONICAL SPRING	19	BL800A-11309
14	CAM PUSHER	1	BL800A-11310
15	CAM PIN	1	BL800A-11314
16	SPINDLE BUSH	1	BL800K-11330
17	SPINDLE WAVE WASHER	2	BL800A-11328
18	COLLET CHUCK JOINT	1	BL800K-11320
19	O-RING	2	BL800K-11323
20	DELTRIN JOINT	1	BL800A-11322
21	BALL GUIDE STOPPER	1	BL800A-11002
22	HAND CAP COVER	1	BL800A-11101
23	CAM	1	BL800K-11201
24	BALL	2	BL800A-11211
25	BALL RIM	2	BL800A-11212
26	O-RING	1	BL800A-11202
27	BALL GUIDE INNER	1	BL800A-11205
28	HANDLE SPRING	1	BL800A-11206
29	BALL BEARING	1	BL800A-11208
30	MOTOR CASE COVER	1	MAX88K-11001
31	MOTOR CASE HEAD	1	MAX88K-11005
32	MOTOR CASE	1	MAX88K-11002
33	FLAT HEAD BOLT	2	M2xP0.4xL4
34	BALL BEARING	1	MAX88A-11108
35	Nd BOND MAGNET	1	MAX88A-11003
36	ARMATURE ASSY	1	MAX88K-11100
37	WASHER	1	NX100S-11107
38	BALL BEARING	1	MAX88A-11109
39	BRUSH HOLDER ASSY	1	NX100S-11200
40	O-RING	1	Ø8x1
41	WAVE WASHER	1	BL800A-11328
42	FLAT WASHER	1	NX100S-11500
43	CARBON ASSY	2	NX100S-11400
44	FAN HEAD BOLT	2	M2xP0.4xL4
45	CONNECTOR (L/R)	2	NX100S-11300
46	CORD ASSY	1	NX100S-11700
47	CAP	1	MAX88K-11800
48	SPINDLE ASSY	1	BL800A-11300
49	HEAD ASSY	1	BL800A-11000
50	BODY ASSY	1	MAX88A-12000

