## ERROR CODE: E24

**DESCRIPTION:** Wrong Exposure signal from Buckies. **ERROR TYPE:** Indicative. Does not allow exposition.

**APPLICABLE TO:** All Generators.


**APPEARS WHEN:** At the beginning of exposition.

**INFORMATION / SYMPTOM :** Wrong Exposure signal from Buckies.

## **POSIBLE CAUSES**

Malfunction of the bucky.
Wrong wiring of the bucky.
Wrong bucky selection.

## **ACTIONS**



34 TR-1040R1