

5-4-6 RTB - Distribution Board Bottom

Function of the Distribution Board Bottom (RTB):

- USB2.0 Interface, Board is connected to PC via USB cable
- 5 port USB2.0 Hub for connecting Peripherals
- Feed through DC-Power and Signals for the Console (12V_ATX, 5V_ATX, 5VSB, PWR_On, Start_Key, Loud speaker)
- Connector for ECG –Preamplifier (optional)
- Multiplexer and Amplifier for PC-Sound, Doppler Audio and VCR/DVD-Recorder

5-4-6-1 RTB - Block Diagram




Figure 5-14 RTB - Block diagram